

DE-SCALER

FOR CENTRAL HEATING SYSTEMS

DIRECTIONS FOR USE

- 1. Switch off boiler and drain system to remove any loose deposits
- 2. While refilling the system add Protex De-Scaler carefully.
- 3. When the system is full again turn on boiler and pump and circulate for four to six hours. Ensure radiators are vented frequently during this procedure.
- 4. Drain the system totally. Refill using water, circulate for 10 minutes and drain off in order to rinse. This rinsing procedure is repeated.
- 5. Finally refill the system and treat with Protex Inhibitor to prevent against further scale formation and corrosion.
- 6. Use the self adhesive label to register date of application.

Protex De - Scaler is suitable for use in all new indirect central heating systems including those containing aluminium. Consult Health and Safety data Sheets (attached) before use.

